



# Clear Choice Inc.

2902 Park Six Court

Elkhart, IN 46514

574-970-0198

---

## Humm'V III Operating Instructions

1. Install the head assembly to the Humm'V III base unit. Insert the long pin holder bracket first, then insert the short bracket on the other side. Lock the mop head in place with the attached pin. When using the lambskin pad choose the top holes. Use lower holes when wet mopping or tacking wood floors with micro fiber pad.
2. Attach the plastic tube from the head assembly to the solution connector that exits the pump compartment at the front of the Humm'V III base unit.
3. Install the lift handle to the head assembly by inserting the "J" hook into the lifting bracket. Lift the head assembly off the floor and hook it into the "up" position.
4. Place solution container on the base of the machine. Insert the suction hose into the container of solution. The metal suction filter at the end of the suction hose should be flat on the bottom of the container.
5. Position the Humm'V III on the spot where you are going to begin.
6. Set the "Power On" switch to "On," and press the "Manual Pump" switch and hold until solution flows through the distribution tube onto the floor. Use the lift handle to lower the head assembly down while pushing the machine forward. While lifting and lowering the head assembly, move machine back and forth to saturate the pad with solution. NOTE: Beginning without enough solution on the pad may cause streaking.
7. As you pull the Humm'V III forward, each revolution of the wheels will activate the pump and dispense a certain amount of solution according to the timer setting. NOTE: The machine will only activate the pump when the machine is pulled, pushing the machine **does not** activate the pump.
8. Begin pulling in a straight line. Once the initial line is complete, a "wet edge" must be maintained with an overlap of 3 to 4 inches per pass.

**For operational questions or problems call 1-574-970-0198**